


Bed Frame


San Francisco - Twin

SIMPLIFIED
BUILDING




61-6
Flange

5x




10-6
Single Socket Tee

14x




15-6
Angled Flange

2x




20-6
Side Outlet Elbow

3x




21-6
Side Outlet Tee

5x



- 1/4" Hex



4x

24 Inches

6x

39 Inches

2x

49 Inches




5x

72 Inches



4x

75 Inches


1.




2.



3.



4.



INSTALLATION TIPS

1. Adjust individual fittings to square and level the frame.
2. Use a socket wrench with a 1/4" hex bit for faster assembly.
3. If the frame seems wobbly, there may be a pipe slightly out of place. Loosen a few setscrews in the problem area and adjust as necessary.
4. Finish up your assembly by ensuring all setscrews are tightened properly.
5. Use a sheet of plywood or slat platform underneath the mattress.

